



Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and Modbus funtionality. For monitoring over-, under or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts as well as the use in pressure differential systems. Options available with LCD display and Auto-Zero function. NEMA 4X / IP65 rated enclosure.







Type Overview

Туре	Measuring range [Pa] [Pa]	Measuring range [inch WC] [inch WC]	Communication	Output signal active pressure	Output signal active volumetric flow	Burst pressure	Display type	Additional features
22ADP-55Q	-150250	-0.61	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	-	-
22ADP-55QA	-150250	-0.61	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	-	Auto-Zero
22ADP-55QB	-150250	-0.61	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD	Auto-Zero
22ADP-55QL	-150250	-0.61	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD	-

Technical data

Electrical Data	Nominal voltage	AC/DC 24 V		
	Remark about nominal voltage range	AC 1929 V / DC 1535 V		
	Power consumption AC	4.3 VA		
	Power consumption DC	2.3 W		
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm²		
	Cable entry	Cable gland with strain relief 2x ø6 mm (1/2" NPT conduit adapter included)		
Data bus communication	Communication	Modbus RTU		
	Number of nodes	Modbus see interface description		
Functional Data	Sensor technology	piezo measuring element		
	Application	air		
	Multirange	8 measuring ranges selectable		
	Voltage output	2 x 05 V, 010 V, min. resistance 10 kΩ		
	Output signal active note	Output 05/10 V selectable with switch		
	Display	LCD, 1.14x1.38 in. [29x35 mm] with backlight		
		Measured values: Pa, inch WC (programmable) Measured values volumetric flow: m³/h, cfm (parametrisable)		
	Typical response time	adjustable 0.8 s or 4.0 s		
Measuring Data	Measured values	Differential pressure Volumetric flow		



Technical data sheet

22ADP-55Q..

Fechnical data					
Measuring Data	Measuring fluid air and non-aggressive gases			ve gases	
Specification flow	Measuring range volumetric flow	Default	ole via Modbus setting: 0750'000 cfm ole units: m³/h, m³/s, cfm		
Specification pressure	Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting
		S0	0250	01	
		S1	0100	00.4	Ť
		S2	050	00.2	
		S3	025	00.1	
		S4	-2525	-0.10.1	
		S5	-5050	-0.20.2	
		S6	-100100	-0.40.4	
		S7	-150150	-0.60.6	
	Accuracy	±0.004 i	±0.004 inch WC @ range <1 inch WC ±2.5% FSO (Full Scale Output) / 4 yr.		
	Long term stability	±2.5% F			
Materials	Cable gland	PA6, black			
	Housing	Cover: PC, orange			
			PC, orange		
			8R70, black		
		UV resis			
		UL94 5V	'A		
Safety Data	Protection class IEC/EN	III, Safe	III, Safety Extra-Low Voltage (SELV)		
	Power source UL	Class 2 S	Supply		
	Degree of protection IEC/EN	IP65			
	Degree of protection NEMA/UL	NEMA 4	Х		
	Enclosure	UL Enclo	osure Type 4X		
	EU Conformity	CE Mark	king		
	Certification IEC/EN	IEC/EN	60730-1 and I	EC/EN 60730-2-6	
	Quality Standard	ISO 900	ISO 9001		
	UL 2043 Compliant	Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC			
	Type of action	Type 1	Туре 1		
	Rated impulse voltage supply	0.8 kV			
	Pollution degree	3			
	Ambient humidity	Max. 95	% RH, non-co	ndensing	
	Ambient temperature	-1050	°C [15122°F]	
	Fluid temperature		°C [15122°F		
		-4176			



Safety Notes

Remarks



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.


The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Automated zero-point calibration (Auto	Transmitters equipped with the auto-zero calibration are maintenance-free.		
Zero)	The auto-zero calibration electronically adjusts the transmitter zero every 10 minutes. The function eliminates all output signal drift due to thermal, electronic or mechanical effects. The auto-zero adjustment takes approx. 4 seconds after which the device returns to its normal measuring mode. During the 4 second adjustment period, the output and display values will freeze to the latest measured value.		
Manual zero-point calibration	In normal operation zero-point calibration should be executed every 12 months.		
	Attention! For executing zero-point calibration, the power supply must be connected one hour before.		
	• Release both tube connectors from the pressure ports + and -		
	• Press the button "Manual zero-point calibration" until the LED lights permanently		
	• Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (note and -)		

Indicators and Operation

Indicators

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



1 Fault / sensor failure

- 2 Service / visual inspection due
- **3** TLF (traffic light function) active (thresholds for display colour changes)
 - Radio active (not available)
- 5 Status bar
- Measured value (* appears when TLF function is activated for this value)
- Unit of measure
- 3 Measured value

Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22AP-A08



Technical data sheet

Cable Gland with strain relief ø6...8 mm Dowels Screws 1/2" NPT conduit adapter, 2x ø6 mm

Accessories

Optional accessories	Description	Туре
	Pitot tube, Metal, L 1.5", Tube connection 0.2"	A-22AP-A01
	Pitot tube, Metal, L 4", Tube connection 0.2"	A-22AP-A03
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct
		Sensor Assistant
		Арр
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
	* Bluetooth dongle A-22G-A05	
	Certified and available in North America, European Union, EFTA St	ates and UK.

Service

Tools connection This sensor can be operated and parametrized using the Belimo Assistant App. When using the Belimo Duct Sensor Assistant App, the Bluetooth dongle is required to enable communication between the app and the Belimo sensor. For the standard operation and parametrization of the sensor the Bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above. **Requirement:** - Bluetooth dongle (Belimo Part No: A-22G-A05) - Bluetooth-capable smartphone - Belimo Duct Sensor Assistant App (Google Play & Apple App Store) Procedure: - Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB - Connect Bluetooth-capable smartphone with Bluetooth dongle - Select parametrization in the Belimo Assistant App BELIMC




Wiring Diagram




Supply from isolating transformer.


The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination. Modbus-GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.





Dimensions





Туре	Weight
22ADP-55Q	0.90 lb [0.41 kg]
22ADP-55QA	0.93 lb [0.42 kg]
22ADP-55QB	0.97 lb [0.44 kg]
22ADP-55QL	0.95 lb [0.43 kg]

Further documentation

- Modbus Interface description
- Installation instructions